


Stabil-Mate Parts List - Pump Unit

1008 Manifold
1009 Valve
1010 O Ring
1011 Elbow
1012 Pump Box
1013 Latch
1014 Cover
1015 Lid
1016 Filler Plug
1017 Pump Body
1018 Tube
1019 Pump Spindle

1020 Lever
1021 Lever Bracket
1022 Spindle Bolt
1023 Spindle Locknut
1024 Lever Link
1025 Handle
1026 Seal
1027 Manifold Union
1028 Union
1029 Union Nut
1033 Washer



Stabil-Mate Parts List - Stabiliser

1001-LH	Skid Mounting Bracket	1006	Cylinder
1001-RH	Skid Mounting Bracket	1007	Cylinder Pivot
1002	Skid	1028	Union
1003-LH	Spring	1029	Union Nut
1003-RH	Spring	1030	Cylinder Pivot Circlip
1004	Skid Pivot	1031	Skid Pivot Circlip
1005	Skid Pivot Spacer	1032	Split Pin

(LH ASSEMBLY ILLUSTRATED)

