WINEGARD® Wingman® Antenna

For use with Sensar II or III Antenna Heads Manufactured after 1990


Enhances UHF Performance. No tools required for installation. No wires to connect.

Parts Included:

(1) Wingman unit, (4) Push Rivet NOT ALL PUSH RIVETS WILL BE USED WITH ALL MODELS.

Installation:

NOTE: Skip steps 1, 2 & 5 for antennas mounted to a permanent structure.



- 1. Allow at least 10" of clearance between the Sensar® and the nearest obstruction or the edge of the roof.
- 2. Raise the Sensar® antenna.
- 3. Remove the rubber bumpers from the bottom of the Sensar. This can be done with your fingers or pliers.
- 4. Line the holes in the Wingman up with the holes from which you removed the rubber bumpers. Gray models will not have bumpers.
- 5. Insert the push rivets provided into these holes. Push the rivet tabs until they click and lock into place.
- 6. Lower Antenna.



Winegard Company • 3000 Kirkwood Street • Burlington, Iowa 52601-2000 • FAX 319/754-0787 • www.winegard.com Printed in U.S.A. © Winegard Company, 2008 Rev5 12-13 2452167

WINEGARD® Wingman® Antenna

For use with Sensar II or III Antenna Heads Manufactured after 1990


Enhances UHF Performance. No tools required for installation. No wires to connect.

Parts Included:

(1) Wingman unit, (4) Push Rivet NOT ALL PUSH RIVETS WILL BE USED WITH ALL MODELS.

Installation:

NOTE: Skip steps 1, 2 & 5 for antennas mounted to a permanent structure.



- 1. Allow at least 10" of clearance between the Sensar® and the nearest obstruction or the edge of the roof.
- 2. Raise the Sensar® antenna.
- 3. Remove the rubber bumpers from the bottom of the Sensar. This can be done with your fingers or pliers.
- 4. Line the holes in the Wingman up with the holes from which you removed the rubber bumpers. Gray models will not have bumpers.
- 5. Insert the push rivets provided into these holes. Push the rivet tabs until they click and lock into place.
- 6. Lower Antenna.

